

Seznam TV frekvencí podle čísel kanálů

R1	49.75 Mhz	C22	479.25 Mhz
R2	59.25 Mhz	C23	487.25 Mhz
R3	77.25 Mhz	C24	495.25 Mhz
R4	85.25 Mhz	C25	503.25 Mhz
R5	93.25 Mhz	C26	511.25 Mhz
S1	105.25 Mhz	C27	519.25 Mhz
S2	112.25 Mhz	C28	527.25 Mhz
S3	119.25 Mhz	C29	535.25 Mhz
S4	126.25 Mhz	C30	543.25 Mhz
S5	133.25 Mhz	C31	551.25 Mhz
S6	140.25 Mhz	C32	559.25 Mhz
S7	147.25 Mhz	C33	567.25 Mhz
S8	154.25 Mhz	C34	575.25 Mhz
S9	161.25 Mhz	C35	583.25 Mhz
S10	168.25 Mhz	C36	591.25 Mhz
R6	175.25 Mhz	C37	599.25 Mhz
R7	183.25 Mhz	C38	607.25 Mhz
R8	191.25 Mhz	C39	615.25 Mhz
R9	199.25 Mhz	C40	623.25 Mhz
R10	207.25 Mhz	C41	631.25 Mhz
R11	215.25 Mhz	C42	639.25 Mhz
R12	223.25 Mhz	C43	647.25 Mhz
S11	231.25 Mhz	C44	655.25 Mhz
S12	238.25 Mhz	C45	663.25 Mhz
S13	245.25 Mhz	C46	671.25 Mhz
S14	252.25 Mhz	C47	679.25 Mhz
S15	259.25 Mhz	C48	687.25 Mhz
S16	266.25 Mhz	C49	695.25 Mhz
S17	273.25 Mhz	C50	703.25 Mhz
S18	280.25 Mhz	C51	711.25 Mhz
S19	287.25 Mhz	C52	719.25 Mhz
S20	294.25 Mhz	C53	727.25 Mhz
S21	303.25 Mhz	C54	735.25 Mhz
S22	311.25 Mhz	C55	743.25 Mhz
S23	319.25 Mhz	C56	751.25 Mhz
S24	327.25 Mhz	C57	759.25 Mhz
S25	335.25 Mhz	C58	767.25 Mhz
S26	343.25 Mhz	C59	775.25 Mhz
S27	351.25 Mhz	C60	783.25 Mhz
S28	359.25 Mhz	C61	791.25 Mhz
S29	367.25 Mhz	C62	799.25 Mhz
S30	375.25 Mhz	C63	807.25 Mhz
S31	383.25 Mhz	C64	815.25 Mhz
S32	391.25 Mhz	C65	823.25 Mhz
S33	399.25 Mhz	C66	831.25 Mhz
S34	407.25 Mhz	C67	839.25 Mhz
S35	415.25 Mhz	C68	847.25 Mhz
S36	423.25 Mhz	C69	858.25 Mhz
S37	431.25 Mhz		
S38	439.25 Mhz		
S39	447.25 Mhz		
S40	455.25 Mhz		
S41	463.25 Mhz		
C21	471.25 Mhz		

Posun zvuku

DK norma "+6,5Mhz" východní

BG norma "+5,5Mhz" západní

kanál C je někdy označován také K